

# Atlas aluminum tile

for walls  
and  
ceilings

permanent,  
decorative,  
economical, F.H.A. accepted

## COLORS AVAILABLE IN ALL STOCK SIZES

Gloss White	A-202	Bone White	A-218
California Peach	A-204	Blue Gray	A-220
Desert Tan	A-206	Amber Gold	A-222
Lime Green	A-208	Camellia Pink	A-224
Sky Blue	A-210	Azure Mist	A-226
Choco Brown	A-212	Goldleaf	B-320
Black	A-214	Goldleaf	B-330
Oatmeal	A-216	Goldleaf	B-340

## ATLAS ALUMINUM TILE SPECIFICATIONS

**General:** Atlas Tile manufactured by the Atlas Tile Manufacturing Company of Burbank, California, shall be supplied on walls and ceilings as indicated on the plans or as called for in the specifications.

**Materials:** Atlas Aluminum Tile for walls and ceilings shall be 3S ½ H. alloy, .019 thickness, standard mill finish. The aluminum is anodized to insure proper paint adhesion to the metal and has an anti-corrosive protective covering. The finish is a mechanically applied formulation of ALKYDUREA MELAMINE enamel. Baked in accordance with the manufacturer's standard procedure to insure a high gloss finish.

## ATLAS MASTIC MFG. CO. SPECIFICATIONS

The adhesive is an oil base, waterproof, non-penetrating, non-separating mastic. Compounded to provide the same viscosity and adhesion under all temperatures and humidity conditions without breakdown.

Installation instructions attached.

# ATLAS INSTALLATION INSTRUCTIONS

## Tile & Mastic

For a job of lasting beauty and durability, the wall to be covered should be just as solid as possible, whether of wood, plywood, plaster board or plaster. It is necessary that all cracks and holes be filled with patching plaster and all loose paint, plaster or calomine be removed with a wire brush in order to provide a perfectly smooth surface for your tile. On new construction allow the plaster to dry five to seven days.

For best results, seal the walls with a good wall sealer. If shellac is used as a sealer, use in full strength--two coats, if necessary--and allow it to dry thoroughly before applying ADHESIVE.

Determine low point on the floor. Wall measurements should start from this point. From the low point, measure UP to the height that the walls are to be used; then strike a level line in area where tile is to be used.

Start applications of the tiles in the exact center of the wall. Tiles at each end of the wall will then be trimmed to equal size, giving a perfectly balanced appearance.

ATLAS ADHESIVE should be warmed to approximately 75 degrees f. before application. This can be done by keeping the adhesive in a heated room overnight. When properly warmed apply the adhesive to a wall area of approximately 4' x 5' using an ADHESIVE SPREADING COMB. Ribbons of the adhesive should always run horizontally on the wall.

Tin snips may be used to cut openings for pipes and fixtures. Tiles should not be cut until the fixture is reached and then should be checked for fit before cementing. In cutting tiles to fit inside corners or around sills, if the tin snips are held at a 45 degree angle from the cut, or if a Tile Cutter is used, a satisfactory bevel will be formed on the cut edge of the tiles.

When tiles have been installed over an area of approximately 4' x 5', the joints should be raked and evened. Then use a soft, clean cloth to remove excessive mastic from face of tiles by light and even strokes. Use eraser end of an ordinary pencil or 1/4" hardwood dowel pin, rounded off, or use your finger to very lightly smooth the mastic in the grout.

Your Tile installation may be used within 48 hours after application. However, it is recommended that the tiles not be washed or polished for roughly two weeks after installation in order to permit the cement to firmly set.

In cleaning, use only a mild soap and warm water. Never use kitchen cleanser or strong cleaning fluids. Use Johnson's Jubilee the white clean-up three or four times yearly. This will add years of service to your tile as well as beauty to its natural finish.



# ATLAS TILE MANUFACTURING COMPANY

264 W. Spazier Ave. Burbank, California

THornwall 5-2651

THornwall 5-2652

THornwall 9-4527



# ATLAS INSTALLATION INSTRUCTIONS

## Tile & Mastic

For  
as possible  
and holes  
with a width  
allow

For  
in full strength

From the  
line in area

Wall will

tion. This  
warmed and  
ING COME

until the  
to fit inside  
or if a Tile

be raked and  
tiles by liquid  
pin, round

Y  
recommen  
in order to

In  
strong clea  
This will

Digitized by



ASSOCIATION  
FOR  
PRESERVATION  
TECHNOLOGY,  
INTERNATIONAL  
[www.apti.org](http://www.apti.org)

BUILDING  
TECHNOLOGY  
HERITAGE  
LIBRARY

<https://archive.org/details/buildingtechnologyheritagelibrary>

From the collection of:

Mike Jackson, FAIA

solid  
racks  
red  
struct-

use  
IVE.

at.  
vel

the

ca-  
y  
EAD-

cut  
tiles  
cut,

ould  
f  
vel

is  
on



ATLAS TILE MANUFACTURING  
COMPANY

264 W. Spazier Ave. Burbank, California

THornwall 5-2651

THornwall 5-2652

THornwall 9-4527